



## Laptop Cooling Pad



Games



Business Office



Wind Speed



Light Regulation

### User Manual

Please read this User Manual carefully before use.

### Front View



### Product Specifications:

Material	Metal & ABS
Fan Size	120*120*15mm
Product Size	408*287*35mm
Fan Speed	1100±10%RPM
Rated Current	1.0A±10%
Weight	849g


### Height Settings:



1. Open the stand legs which located in the back of the cooling pad.



2. Open the stand slot in the back of cooling pad (as shown in position B), insert the legs into stand slot.



### Steps:

1. Put the laptop cooler on the desktop or table and then put the laptop on the top of it.
2. Connect the USB cable from the cooler to the laptop.
3. Turn the switch to choose the rotation speed and light mode.



**Offgridtec GmbH**  
Im Gewerbepark 11  
84307 Eggenfelden  
Germany

[www.offgridtec.com](http://www.offgridtec.com)  
[info@offgridtec.com](mailto:info@offgridtec.com)  
+49 8721 91994-00

WEEE-Reg.-No. DE37551136